


Overhead Directional Camera

Part # =3005-110

Capture Directional Count Data
Wirelessly Transmit to CompuCount




This overhead directional counting system is designed to count people entering and exiting a doorway, hallway, or area. This counting system consists of three parts: a closed-circuit television (CCTV) camera wired to the directional interface box with an internal 900 MHz wireless transmitter to send count data to the CompuCount PC server. The camera, interface box and CompuCount all require AC power. A 10baseT Ethernet port is used to connect the CompuCount to the user's computer. Each interface box has its own unique identification code and each CompuCount is assigned its own IP address to identify specific locations.

Key Advantages

- Overhead closed-circuit television (CCTV) camera tracks people entering and leaving.
- Counts are wirelessly transmitted to the CompuCount PC Server attached to your PC or PC network.
- Count data can be exported if one desires to create their own curves, graphs, charts and reports.
- When attached to a video monitor, you can see the marker lines flash when someone crosses the threshold.

Main Features

- 900 MHz Unit with typical indoor range up to 1500 feet
- Individual Address to identify specific locations
- Minimum time between detection is 0.3 seconds
- Camera interface continuously monitors and adjusts for background light levels
- CRC-16 Error Checked Radio Data assures data accuracy
- CompuCount can receive data from up to 16 Walker Wireless Counters in the same radio environment.



Counter Manager
01/14/05 06:37:05

[Per Half Hour](#)
[Per Hour](#)
[Per Day](#)
[Per Week](#)
[Per Month](#)
[Status](#)
[Setup](#)
[Export](#)

Counts Per Half Hour

Starting 01/14/05	12:00 12:30 AM	12:30 1:00 AM	1:00 1:30 AM	1:30 2:00 AM	2:00 2:30 AM	2:30 3:00 AM	3:00 3:30 AM	3:30 4:00 AM	4:00 4:30 AM	4:30 5:00 AM	5:00 5:30 AM	5:30 6:00 AM	Total
Office	0	0	0	0	0	0	0	0	0	2	0	0	2
Stairs	0	0	2	0	0	2	0	0	0	2	0	0	6
Total	0	0	2	0	0	2	0	0	0	4	0	0	

For Use With All
Walker Wireless
Counters

BoostACount

and

CompuCount